

How do I enable and use Time Shift?

Note: Time shift allows you to pause, rewind and replay live TV on the current channel. It will allow you to rewind up to 2 hours (providing the PVR has been on that channel for 2 hrs). First you need to make sure Time Shifting is enabled.

1. Switch on the Beyonwiz PVR and wait for a picture to show on the screen. If a picture doesn't appear, your PVR may need to scan your channels first – See "How do I do a Channel Scan?"
2. Press the **SETUP** button on the remote
3. Using the **ARROW** keys on the remote, navigate to the **MISC** option on the top bar.
4. Make sure the highlighted item is **Preference** (left column) and press **OK** on the remote – the highlighted item should now be **Time Shifting**.
5. Use the **ARROW** keys to highlight **>Enable**, and then press the **OK** button on the remote.
6. Press the **LIVE** button to return to normal viewing

Note: You will need to leave the PVR on a channel for a few minutes to allow the time shift buffer to have data in it before proceeding to the next step.

7. Use the **left ARROW** key to scroll back through the time shift data. A **time bar** shows you (in **red**) where you are currently in the time shift buffer.
8. Use the **right ARROW** key to scroll forward through the time shift data.
9. Use the **PAUSE** button on the remote to pause live TV. Use the **PAUSE** button to resume viewing. **Pause** is displayed on the screen (top right hand side).
10. Use the **STOP** button on the remote to skip ahead to real time live position. **Live** is displayed on the screen (top right hand side).

Note: You can also use the FF and REW and SLOW FWD buttons to move through the time shift buffer. The PLAY button resumes normal play time. The Up and Down ARROW buttons will do 10% jumps through the time shift buffer.

The time shift buffer will empty if you change channels, play another file or go into the setup menu.



FOR MORE DETAILED INFORMATION REFER TO PAGE 49-50 AND 96 OF THE MANUAL